

# Come clean, go clean!



## 3 Easy Steps to Effectively Decontaminate:

### 1: Wash Down - Vehicle and Boot

- Park vehicle or equipment in designated wash down area where contaminants will be trapped in sump.
- Using high pressure water or compressed air, clean all surfaces to remove mud, trash and dirt. Pay special attention to hard to get to areas like chassis, grills and tyre treads. Also clean floor mats and inside cabin floor and foot pedals. Remove any contaminants from footwear.
- If you have hard to remove contaminants use **Hammersley's Fleet Wash** to help quickly remove these contaminants and rinse.

### 2: Decontaminate

- Apply **Hammersley's Pyramine** (a bio-security barrier protector) to all surfaces. Pyramine is dual quaternary providing more powerful performance, faster action and better degradability. Pyramine is odourless, non-irritating, non-staining, non-flammable and non-corrosive.
- **Pyramine** can also be used as a foot bath to decontaminate your boots.
- Use only 4ml's of **Pyramine** per litre to effectively decontaminate.
- **No rinsing of vehicle or equipment is required once Pyramine is applied!**

### 3: Rinse Wash Pad

- Before moving vehicle or equipment, use high pressure water to clean wash pad of all contaminants, allow drying time before moving vehicle and equipment from wash pad to a dry area, avoiding collecting dirt in tyre tread.
- A final clean of the wash pad area, so any contaminants are washed into sump area, reduces the risk of spreading seeds etc. by other vehicles, equipment or wind.